

```

// ===== DetectorConstruction.cc Class =====
//
// Developed by Bryan V. Egner, Darren E. Holland, and Julie V. Logan
// Modified by Darren Holland 2020-11-02
// =====
//
// This file creates creates the model geometry, materials, and also the applies
// the functional detector capabilities to utilize built-in scorers
// =====
//
#include "B4DetectorConstruction.hh"
// Geant4 Material Classes:
#include "G4Material.hh"
#include "G4NistManager.hh"
// Geant4 Geometric Shapes:
#include "G4Box.hh"
#include "G4UnionSolid.hh"
#include "G4Sphere.hh"
#include "G4LogicalVolume.hh"
#include "G4PVPlacement.hh"
#include "G4PVReplica.hh"
#include "G4Tubs.hh"
#include "G4Orb.hh"
#include "G4SubtractionSolid.hh"
#include "G4GeometryManager.hh"
#include "G4PhysicalVolumeStore.hh"
#include "G4LogicalVolumeStore.hh"
#include "G4SolidStore.hh"
#include "G4VisAttributes.hh"
#include "G4Colour.hh"
#include "G4PhysicalConstants.hh"
#include "G4SystemOfUnits.hh"
#include "G4UnitsTable.hh"
#include <iterator>
#include <vector>
// CADMESH //
#include "G4String.hh"
#include "G4TessellatedSolid.hh"
#include "G4TriangularFacet.hh"
#include "G4QuadrangularFacet.hh"
#include "G4Tet.hh"
#include "G4UIcommand.hh"
// GEANT4 //
#include "globals.hh"
#include "G4ThreeVector.hh"
#include "G4Transform3D.hh"
#include "G4AssemblyVolume.hh"
#include "Settings.hh"
#include "G4SDManager.hh"
#include "G4MultiFunctionalDetector.hh"
#include "G4VPrimitiveScorer.hh"
#include "G4PSEnergyDeposit.hh"

#include <iostream>
#include <fstream>

using namespace std;
// Create instance and variable for checking geometry overlaps
B4DetectorConstruction::B4DetectorConstruction()
: G4VUserDetectorConstruction(),
  fCheckOverlaps(true)
{}

// Destroy instance

```

```

B4DetectorConstruction::~B4DetectorConstruction()
{}

// Create volumes
G4VPhysicalVolume* B4DetectorConstruction::Construct()
{
    return DefineVolumes();
}

// =====
//
// Define volumes
// =====
//
G4VPhysicalVolume* B4DetectorConstruction::DefineVolumes()
{
    // Initializes Variables/Constant Values (type):
    G4double z, a, fractionmass, density;
    G4String name, symbol;
    G4int ncomponents, natoms;
    // Initiate Nist Manager for Materials:
    G4NistManager* nistManager = G4NistManager::Instance();

    //
    ===== //
    // Get materials
    //
    ===== //
    // Environmental Materials:
    // Air (0.00120479 g/cc):
    G4Material* air_mat = nistManager->FindOrBuildMaterial("G4_AIR");

    // Mask Materials:
    // Acrylic (1.19):
    G4Material* plexi_mat = nistManager->FindOrBuildMaterial("G4_PLEXIGLASS");

    // Create materials for organic Elements: Carbon, Hydrogen, Oxygen:
    // Element properties
    a = 1.00794*g/mole;
    G4Element* ele_H = new G4Element("Hydrogen", symbol="H", z=1., a);
    G4Material* G4_H = nistManager->FindOrBuildMaterial("G4_H");

    a = 15.999*g/mole;
    G4Element* ele_O = new G4Element("Oxygen", symbol="O", z=8., a);
    G4Material* G4_O = nistManager->FindOrBuildMaterial("G4_O");

    a = 12.0107*g/mole;
    G4Element* ele_C = new G4Element("Carbon", symbol="C", z=6., a);
    G4Material* G4_C = nistManager->FindOrBuildMaterial("G4_C");

    // Create materials for elements
    G4Material* G4_Mg = nistManager->FindOrBuildMaterial("G4_Mg");
    G4Material* G4_Al = nistManager->FindOrBuildMaterial("G4_Al");
    G4Material* G4_Si = nistManager->FindOrBuildMaterial("G4_Si");
    G4Material* G4_Ti = nistManager->FindOrBuildMaterial("G4_Ti");
    G4Material* G4_Cr = nistManager->FindOrBuildMaterial("G4_Cr");
    G4Material* G4_Mn = nistManager->FindOrBuildMaterial("G4_Mn");
    G4Material* G4_Fe = nistManager->FindOrBuildMaterial("G4_Fe");
    G4Material* G4_Cu = nistManager->FindOrBuildMaterial("G4_Cu");
    G4Material* G4_Zn = nistManager->FindOrBuildMaterial("G4_Zn");

    // Detector Materials:
    // NaI Scintillator (g/cc):
    G4Material* NaI_mat = nistManager->FindOrBuildMaterial("G4_SODIUM_IODIDE");

```

```

// Aluminum Alloy Casing 6061 (2.7 g/cc): (PNNL-15870 Compendium)
G4Material* AlAlloy6061 = new G4Material(name="AlAlloy6061", density=
2.7*g/cm3, ncomponents=9);
    AlAlloy6061->AddMaterial(G4_Mg, fractionmass=0.01);
    AlAlloy6061->AddMaterial(G4_Al, fractionmass=0.97207);
    AlAlloy6061->AddMaterial(G4_Si, fractionmass=0.006);
    AlAlloy6061->AddMaterial(G4_Ti, fractionmass=0.00088);
    AlAlloy6061->AddMaterial(G4_Cr, fractionmass=0.001950);
    AlAlloy6061->AddMaterial(G4_Mn, fractionmass=0.000880);
    AlAlloy6061->AddMaterial(G4_Fe, fractionmass=0.004090);
    AlAlloy6061->AddMaterial(G4_Cu, fractionmass=0.002750);
    AlAlloy6061->AddMaterial(G4_Zn, fractionmass=0.00146);

// PMT Materials:
// Pseudo PMT Material (0.39 g/cc): (assumed to be Aluminum with a lighter
density)
density = 0.39*g/cm3;
G4Material* PMT_Mat = new G4Material("PMT_Mat",density,ncomponents=1);
    PMT_Mat->AddMaterial(G4_Al, fractionmass=1.0);
// Borosilicate Glass (2.23 g/cc):
G4Material* BoroSi_Glass = nistManager->FindOrBuildMaterial("G4_Pyrex_Glass");

//
===== //
// Define Geometry/Fill with Materials
//
===== //
// World:
// The world is a sphere with radius that is 1 cm larger than the source
distance
G4double worldRadius = (Settings::SourceDist+1)*cm; // Sphere Radius
G4VSolid* worldS
    = new G4Orb("World", worldRadius); // Sphere

G4LogicalVolume* worldLV
    = new G4LogicalVolume(
        worldS,          // its solid
        air_mat,         // its material
        "World");        // its name

G4VPhysicalVolume* worldPV
    = new G4PVPlacement(
        0,               // no rotation
        G4ThreeVector(), // at (0,0,0)
        worldLV,         // its logical volume
        "World",         // its name
        0,               // its mother volume
        false,           // no boolean operation
        0,               // copy number
        fCheckOverlaps); // checking overlaps
worldLV->SetVisAttributes(G4VisAttributes::Invisible); // Makes world
invisible in visualization

// The mask geometry
//MASK: READ IN THE NODES TO 3 VECTORS (x,y,z)
ifstream infile;
infile.open(Settings::fname_nodes);
std::vector<double> xVals;
std::vector<double> yVals;
std::vector<double> zVals;
string line;
while(getline(infile,line)) // To get you all the lines.
{

```

```

        istringstream buf(line);
        istream_iterator<std::string> beg(buf), end;
        vector<std::string> tokens(beg, end);
        // remove the comma
        tokens[0].pop_back();
        tokens[1].pop_back();
        tokens[2].pop_back();

        xVals.push_back(stod (tokens[1].c_str()));
        yVals.push_back(stod (tokens[2].c_str()));
        zVals.push_back(stod (tokens[3].c_str()));
    }
infile.close();

// Total mass from all tetrahedrons
double totMass = 0.;

// Create volume
G4AssemblyVolume * assembly = new G4AssemblyVolume();
G4Transform3D assembly_transform = G4Translate3D();

//READ IN THE ELEMENTS TO 8 VECTORS (1,2,3,4,5,6,7,8)
ifstream infile2;
infile2.open(Settings::fname_ele);
std::vector<int> onePoint;
std::vector<int> twoPoint;
std::vector<int> threePoint;
std::vector<int> fourPoint;
std::vector<int> fivePoint;
std::vector<int> sixPoint;
std::vector<int> sevenPoint;
std::vector<int> eightPoint;
while(getline(infile2,line)) // To get you all the lines.
{
    istringstream buf(line);
    istream_iterator<std::string> beg(buf), end;
    vector<std::string> tokens(beg, end);
    //remove the comma
    tokens[0].pop_back();
    tokens[1].pop_back();
    tokens[2].pop_back();
    tokens[3].pop_back();
    tokens[4].pop_back();
    tokens[5].pop_back();
    tokens[6].pop_back();
    tokens[7].pop_back();

    onePoint.push_back(stoi (tokens[1].c_str()));
    twoPoint.push_back(stoi (tokens[2].c_str()));
    threePoint.push_back(stoi (tokens[3].c_str()));
    fourPoint.push_back(stoi (tokens[4].c_str()));
    fivePoint.push_back(stoi (tokens[5].c_str()));
    sixPoint.push_back(stoi (tokens[6].c_str()));
    sevenPoint.push_back(stoi (tokens[7].c_str()));
    eightPoint.push_back(stoi (tokens[8].c_str()));
}
infile2.close();
// Set visualization options
G4VisAttributes* visAttributes2 = new G4VisAttributes(G4Colour(0.0, 1.0,
0.0)); //green
G4VisAttributes* visAttributes3 = new G4VisAttributes(G4Colour(0.0, 1.0,
0.0)); //green
G4VisAttributes* visAttributes4 = new G4VisAttributes(G4Colour(0.0, 1.0,
0.0)); //green

```

```

    G4VisAttributes* visAttributes5 = new G4VisAttributes(G4Colour(0.0, 1.0,
0.0)); //green
    G4VisAttributes* visAttributes6 = new G4VisAttributes(G4Colour(0.0, 1.0,
0.0)); //green

    G4RotationMatrix * element_rotation = new G4RotationMatrix();
    G4ThreeVector element_position = G4ThreeVector();

    // Create tessellated solid according to the read in lists and add to assembly
    for (int i=0; i<onePoint.size(); i++) {
        // Get points on tessellated solid
        G4ThreeVector p1 = G4ThreeVector(xVals[onePoint[i]-1]*cm,
yVals[onePoint[i]-1]*cm, zVals[onePoint[i]-1]*cm);
        G4ThreeVector p2 = G4ThreeVector(xVals[twoPoint[i]-1]*cm,
yVals[twoPoint[i]-1]*cm, zVals[twoPoint[i]-1]*cm);
        G4ThreeVector p3 = G4ThreeVector(xVals[threePoint[i]-1]*cm,
yVals[threePoint[i]-1]*cm, zVals[threePoint[i]-1]*cm);
        G4ThreeVector p4 = G4ThreeVector(xVals[fourPoint[i]-1]*cm,
yVals[fourPoint[i]-1]*cm, zVals[fourPoint[i]-1]*cm);
        G4ThreeVector p5 = G4ThreeVector(xVals[fivePoint[i]-1]*cm,
yVals[fivePoint[i]-1]*cm, zVals[fivePoint[i]-1]*cm);
        G4ThreeVector p6 = G4ThreeVector(xVals[sixPoint[i]-1]*cm,
yVals[sixPoint[i]-1]*cm, zVals[sixPoint[i]-1]*cm);
        G4ThreeVector p7 = G4ThreeVector(xVals[sevenPoint[i]-1]*cm,
yVals[sevenPoint[i]-1]*cm, zVals[sevenPoint[i]-1]*cm);
        G4ThreeVector p8 = G4ThreeVector(xVals[eightPoint[i]-1]*cm,
yVals[eightPoint[i]-1]*cm, zVals[eightPoint[i]-1]*cm);

        // Create unique name
        G4String tess_name = G4String("Mask_tess_") +
G4UIcommand::ConvertToString(i);

        // First declare a tessellated solid
        auto solidTarget = new G4TessellatedSolid(tess_name +
G4String("_solid"));
        // Define the facets which form the solid
        G4QuadrangularFacet *facet1 = new G4QuadrangularFacet
(p4,p3,p2,p1,ABSOLUTE);
        G4QuadrangularFacet *facet2 = new G4QuadrangularFacet
(p5,p6,p7,p8,ABSOLUTE);
        G4QuadrangularFacet *facet3 = new G4QuadrangularFacet
(p8,p7,p3,p4,ABSOLUTE);
        G4QuadrangularFacet *facet4 = new G4QuadrangularFacet
(p1,p5,p8,p4,ABSOLUTE);
        G4QuadrangularFacet *facet5 = new G4QuadrangularFacet
(p1,p2,p6,p5,ABSOLUTE);
        G4QuadrangularFacet *facet6 = new G4QuadrangularFacet
(p6,p2,p3,p7,ABSOLUTE);
        // Now add the facets to the solid
        solidTarget->AddFacet((G4VFacet*) facet1);
        solidTarget->AddFacet((G4VFacet*) facet2);
        solidTarget->AddFacet((G4VFacet*) facet3);
        solidTarget->AddFacet((G4VFacet*) facet4);
        solidTarget->AddFacet((G4VFacet*) facet5);
        solidTarget->AddFacet((G4VFacet*) facet6);

        // Finally declare the solid is complete and create logical volume
        solidTarget->SetSolidClosed(true);
        G4LogicalVolume * tess_logical = new G4LogicalVolume(solidTarget,
// Set mask material
        plexi_mat, tess_name + G4String("_logical"), 0, 0, 0);
        // Add mass and place in volume
        totMass = totMass + tess_logical->GetMass();
        assembly->AddPlacedVolume(tess_logical, assembly_transform);
    }

```

```

// Set visulization options
visAttributes2->SetVisibility(true);
visAttributes3->SetVisibility(true);
visAttributes4->SetVisibility(true);
visAttributes5->SetVisibility(true);
visAttributes6->SetVisibility(true);
// Color mask
if (i % 2 == 0) {
    tess_logical->SetVisAttributes(visAttributes2); }
if (i % 2 == 1) {
    tess_logical->SetVisAttributes(visAttributes3); }
}
// Add assembly to world
assembly->MakeImprint(worldLV, assembly_transform, 0, 0);

// Print out and save the total mask mass
G4cout << "***** TO CHECK ***** the mass of the mask was: " <<
G4BestUnit(totMass, "Mass") << G4endl;
string fname_mass=Settings::fname_out + "mass.txt";
ofstream ofile;
ofile.open (fname_mass, ios::out);      // ascii file
ofile << "Mass " << G4BestUnit(totMass, "Mass");
ofile.close();
// END OF GENERATING MASK GEOMETRY

//
===== //
// Add other system components
//
===== //
// For this model there are currently 13 different components used, more may
be added:
//      1.) NaI detector
//      2.) Cell Glass Window
//      3.) End-Cap Top
//      4.) End Cap Sides
//      5.) Upper End-Cap Flange
//      6.) Lower End-Cap Flange
//      7.) PMT
//      8.) Upper PMT Holder
//      9.) Lower PMT Holder
//      10.) PMT Holder Back
//      11.) Detector Lid
//      12.) Detector Tube
//      13.) Mask Holder

// Detector Geometry
// 1.) Cylindrical Scintillator:
G4Tubs* detectorNaI_Solid
= new G4Tubs("Detect",          // its name
    0.*cm,                      // inner radius (cylinder)
    Settings::DetRad*cm,        // outer radius
    Settings::DetHeight*cm,     // half height
    0.*deg,                     // start angle
    360.*deg);                 // end angle
G4LogicalVolume* detectorNaI_Logical
= new G4LogicalVolume(
    detectorNaI_Solid,          // its solid
    NaI_mat,                    // its material
    "DetectLV");               // its name
G4VPhysicalVolume* detectorNaI_Physical
= new G4PVPlacement(
    0,                          // no rotation
    G4ThreeVector(0.*cm,0.*cm,0.*cm), // center

```

```

        detectorNaI_Logical,    // its logical volume

        "Detect",              // its name
        worldLV,               // its mother volume
        false,                 // no boolean operation
        0,                     // copy number
        fCheckOverlaps);      // checking overlaps
// Detector visualization
G4VisAttributes* visAttributes9 = new G4VisAttributes(G4Colour(0.0, 0.0,
1.0)); // Blue
detectorNaI_Logical->SetVisAttributes(visAttributes9);

// 2.) Glass Cell Cap: Borofloat Window --->Borosilicate glass
G4Tubs* CellWindow_Solid
    = new G4Tubs("CellWindow",           // its name
        0.*cm,                          // inner radius (cylinder)
        1.6002*cm,                      // outer radius
        0.2413*cm,                      // half height
        0.*deg,                         // start angle
        360.*deg);                     // end angle
G4LogicalVolume* CellWindow_Logical
    = new G4LogicalVolume(
        CellWindow_Solid,               // its solid
        BoroSi_Glass,                  // its material
        "CellWindow");                 // its name
G4VPhysicalVolume* CellWindow_Physical
    = new G4PVPlacement(
        0,                             // no rotation
        G4ThreeVector(0.*cm,0.*cm,-1.5113*cm), // center
        CellWindow_Logical,            // its logical volume
        "CellWindow",                 // its name
        worldLV,                      // its mother volume
        false,                        // no boolean operation
        0,                            // copy number
        fCheckOverlaps);              // checking overlaps
// Glass cell cap visualization
G4VisAttributes* visAttributes10 = new G4VisAttributes(G4Colour(1.0, 0.0,
1.0)); // Magenta
CellWindow_Logical->SetVisAttributes(visAttributes10);

// 3.) Al End-Cap Face: Aluminum
G4Tubs* CellAlEndCapFace_Solid
    = new G4Tubs("CellAlEndCapFace",    // its name
        0.*cm,                          // inner radius (cylinder)
        1.4224*cm,                      // outer radius
        0.0762*cm,                      // half height
        0.*deg,                         // start angle
        360.*deg);                     // end angle
G4LogicalVolume* CellAlEndCapFace_Logical
    = new G4LogicalVolume(
        CellAlEndCapFace_Solid,         // its solid
        AlAlloy6061,                   // its material
        "CellAlEndCapFace");           // its name
G4VPhysicalVolume* CellAlEndCapFace_Physical
    = new G4PVPlacement(
        0,                             // no rotation
        G4ThreeVector(0.*cm,0.*cm,1.3462*cm), // center
        CellAlEndCapFace_Logical,      // its logical volume
        "CellAlEndCapFace",           // its name
        worldLV,                      // its mother volume
        false,                        // no boolean operation
        0,                            // copy number
        fCheckOverlaps);              // checking overlaps
// Al end-cap face visualization

```

```

G4VisAttributes* visAttributes11 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
CellAlEndCapFace_Logical->SetVisAttributes(visAttributes11);

// 4.) Al End-Cap Sides: Aluminum
G4Tubs* CellAlEndCapSides_Solid
    = new G4Tubs("CellAlEndCapSides",
        1.27*cm, // its name
        1.4224*cm, // inner radius (cylinder)
        1.27*cm, // outer radius
        0.*deg, // half height
        360.*deg); // start angle
G4LogicalVolume* CellAlEndCapSides_Logical
    = new G4LogicalVolume(
        CellAlEndCapSides_Solid, // its solid
        AlAlloy6061, // its material
        "CellAlEndCapSides"); // its name
G4VPhysicalVolume* CellAlEndCapSides_Physical
    = new G4PVPlacement(
        0, // no rotation
        G4ThreeVector(0.*cm,0.*cm,0.*cm), // center
        CellAlEndCapSides_Logical, // its logical volume
        "CellAlEndCapSides", // its name
        worldLV, // its mother volume
        false, // no boolean operation
        0, // copy number
        fCheckOverlaps); // checking overlaps
// Al end-cap sides visualization
G4VisAttributes* visAttributes12 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // white
CellAlEndCapSides_Logical->SetVisAttributes(visAttributes12);

// 5.) Al End-Cap Flange Top: Aluminum
G4Tubs* CellAlEndCapFlangeTop_Solid
    = new G4Tubs("CellAlEndCapFlangeTop",
        1.4224*cm, // its name
        1.9050*cm, // inner radius (cylinder)
        0.4953*cm, // outer radius
        0.*deg, // half height
        360.*deg); // start angle
G4LogicalVolume* CellAlEndCapFlangeTop_Logical
    = new G4LogicalVolume(
        CellAlEndCapFlangeTop_Solid, // its solid
        AlAlloy6061, // its material
        "CellAlEndCapFlangeTop"); // its name
G4VPhysicalVolume* CellAlEndCapFlangeTop_Physical
    = new G4PVPlacement(
        0, // no rotation
        G4ThreeVector(0.*cm,0.*cm,-0.7747*cm), // center
        CellAlEndCapFlangeTop_Logical, // its logical volume
        "CellAlEndCapFlangeTop", // its name
        worldLV, // its mother volume
        false, // no boolean operation
        0, // copy number
        fCheckOverlaps); // checking overlaps
// Al end-cap flange top visualization
G4VisAttributes* visAttributes13 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // white
CellAlEndCapFlangeTop_Logical->SetVisAttributes(visAttributes13);

// 6.) Al End-Cap Flange Bottom: Aluminum
G4Tubs* CellAlEndCapFlangeBottom_Solid
    = new G4Tubs("CellAlEndCapFlangeBottom",
        1.6002*cm, // its name
        // inner radius (cylinder)

```



```

        1.9050*cm,          // outer radius
        0.2413*cm,          // half height
        0.*deg,             // start angle
        360.*deg);         // end angle
G4LogicalVolume* CellAlEndCapFlangeBottom_Logical
= new G4LogicalVolume(
    CellAlEndCapFlangeBottom_Solid,    // its solid
    AlAlloy6061,                       // its material
    "CellAlEndCapFlangeBottom");       // its name
G4VPhysicalVolume* CellAlEndCapFlangeBottom_Physical
= new G4PVPlacement(
    0,                                // no rotation
    G4ThreeVector(0.*cm,0.*cm,-1.5113*cm), // center
    CellAlEndCapFlangeBottom_Logical,  // its logical volume
    "CellAlEndCapFlangeBottom",        // its name
    worldLV,                           // its mother volume
    false,                             // no boolean operation
    0,                                 // copy number
    fCheckOverlaps);                  // checking overlaps
// Al end-cap flange bottom visualization
G4VisAttributes* visAttributes14 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // white
CellAlEndCapFlangeBottom_Logical->SetVisAttributes(visAttributes14);

// 7.) PMT: Psuedo material --> Al w/ low density (0.39 g/cc)
G4Tubs* PMT_Solid
= new G4Tubs("PMT",                // its name
    0.*cm,                          // inner radius (cylinder)
    1.4250*cm,                      // outer radius
    4.6*cm,                         // half height
    0.*deg,                         // start angle
    360.*deg);                     // end angle
G4LogicalVolume* PMT_Logical
= new G4LogicalVolume(
    PMT_Solid,                      // its solid
    PMT_Mat,                       // its material
    "PMT");                         // its name
G4VPhysicalVolume* PMT_Physical
= new G4PVPlacement(
    0,                              // no rotation
    G4ThreeVector(0.*cm,0.*cm,-6.3526*cm), // center
    PMT_Logical,                   // its logical volume
    "PMT",                         // its name
    worldLV,                       // its mother volume
    false,                         // no boolean operation
    0,                             // copy number
    fCheckOverlaps);              // checking overlaps
// PMT visualization
G4VisAttributes* visAttributes15 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // white
PMT_Logical->SetVisAttributes(visAttributes15);

// 8.) PMT Holder Upper Part
G4Tubs* PMTHolderUpperPart_Solid_Sleeve
= new G4Tubs("PMTHolderUpperPart", // its name
    ( 1.7399)*cm,                  // innerR
    (1.905)*cm,                    // outer radius
    (0.635)*cm,                    // half height
    0.*deg,                        // start angle
    360.*deg);                     // end angle

G4LogicalVolume* PMTHolderUpperPart_Logical_Sleeve
= new G4LogicalVolume(
    PMTHolderUpperPart_Solid_Sleeve, // its solid

```

```

        AlAlloy6061,                // its material
        "PMTHolderUpperPart");      // its name

G4VPhysicalVolume* PMTHolderUpperPart_Physical_Sleeve
= new G4PVPlacement(
    0,                               // no rotation
    G4ThreeVector(0.*cm,0.*cm,(-2.3876)*cm), // center
    PMTHolderUpperPart_Logical_Sleeve, // its logical volume
    "PMTHolderUpperPart",           // its name
    worldLV,                        // its mother volume
    false,                          // no boolean operation
    0,                              // copy number
    fCheckOverlaps);               // checking overlaps
// PMT holder upper part visualization
G4VisAttributes* visAttributes16 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
PMTHolderUpperPart_Logical_Sleeve->SetVisAttributes(visAttributes16);

// 9.) PMT Holder Lower Part
G4Tubs* PMTHolderLowerPart_Solid_Sleeve
= new G4Tubs("PMTHolderLowerPart", // its name
    ( 1.7399)*cm,                  // innerR
    (1.9844)*cm,                  // outer radius
    (7.0765)*cm,                  // half height
    0.*deg,                       // start angle
    360.*deg);                   // end angle

G4LogicalVolume* PMTHolderLowerPart_Logical_Sleeve
= new G4LogicalVolume(
    PMTHolderLowerPart_Solid_Sleeve, // its solid
    AlAlloy6061,                    // its material
    "PMTHolderLowerPart");          // its name

G4VPhysicalVolume* PMTHolderLowerPart_Physical_Sleeve
= new G4PVPlacement(
    0,                               // no rotation
    G4ThreeVector(0.*cm,0.*cm,(-10.0991)*cm), // center
    PMTHolderLowerPart_Logical_Sleeve, // its logical
volume
    "PMTHolderLowerPart",           // its name
    worldLV,                        // its mother volume
    false,                          // no boolean operation
    0,                              // copy number
    fCheckOverlaps);               // checking overlaps
// PMT holder lower part visualization
G4VisAttributes* visAttributes17 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
PMTHolderLowerPart_Logical_Sleeve->SetVisAttributes(visAttributes17);

// 10.) PMT Holder Bottom Part
G4Tubs* PMTHolderBottomPart_Solid_Sleeve
= new G4Tubs("PMTHolderBottomPart", // its name
    (0.)*cm,                       // innerR
    (1.7399)*cm,                  // outer radius
    (0.0762)*cm,                  // half height
    0.*deg,                       // start angle
    360.*deg);                   // end angle

G4LogicalVolume* PMTHolderBottomPart_Logical_Sleeve
= new G4LogicalVolume(
    PMTHolderBottomPart_Solid_Sleeve, // its solid
    AlAlloy6061,                    // its material
    "PMTHolderBottomPart");          // its name

```

```

G4VPhysicalVolume* PMTHolderBottomPart_Physical_Sleeve
= new G4PVPlacement(
    0, // no rotation
    G4ThreeVector(0.*cm,0.*cm,(-17.0994)*cm), // center
    PMTHolderBottomPart_Logical_Sleeve, // its logical
volume
    "PMTHolderBottomPart", // its name
    worldLV, // its mother volume
    false, // no boolean operation
    0, // copy number
    fCheckOverlaps); // checking overlaps
// PMT holder bottom part visualization
G4VisAttributes* visAttributes18 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
PMTHolderBottomPart_Logical_Sleeve->SetVisAttributes(visAttributes18);

// 11.) Detector Lid
G4Tubs* DetectorLid_Solid_Sleeve
= new G4Tubs("DetectorLid", // its name
    (0.)*cm, // innerR
    (1.9844)*cm, // outer radius
    (0.19685)*cm, // half height
    0.*deg, // start angle
    360.*deg); // end angle

G4LogicalVolume* DetectorLid_Logical_Sleeve
= new G4LogicalVolume(
    DetectorLid_Solid_Sleeve, // its solid
    AlAlloy6061, // its material
    "DetectorLid"); // its name

G4VPhysicalVolume* DetectorLid_Physical_Sleeve
= new G4PVPlacement(
    0, // no rotation
    G4ThreeVector(0.*cm,0.*cm,(2.37715)*cm), // center
    DetectorLid_Logical_Sleeve, // its logical volume
    "DetectorLid", // its name
    worldLV, // its mother volume
    false, // no boolean operation
    0, // copy number
    fCheckOverlaps); // checking overlaps
// Detector lid visualization
G4VisAttributes* visAttributes19 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
DetectorLid_Logical_Sleeve->SetVisAttributes(visAttributes19);

// 12.) Detector Tube
G4Tubs* DetectorTube_Solid_Sleeve
= new G4Tubs("DetectorTube", // its name
    (1.9844)*cm, // innerR
    (2.2225)*cm, // outer radius
    (19.58085)*cm, // half height
    0.*deg, // start angle
    360.*deg); // end angle

G4LogicalVolume* DetectorTube_Logical_Sleeve
= new G4LogicalVolume(
    DetectorTube_Solid_Sleeve, // its solid
    AlAlloy6061, // its material
    "DetectorTube"); // its name

G4VPhysicalVolume* DetectorTube_Physical_Sleeve
= new G4PVPlacement(
    0, // no rotation

```

```

        G4ThreeVector(0.*cm,0.*cm,(-17.00685)*cm), // center
        DetectorTube_Logical_Sleeve, // its logical volume
        "DetectorTube", // its name
        worldLV, // its mother volume
        false, // no boolean operation
        0, // copy number
        fCheckOverlaps); // checking overlaps
// Detector tube visualization
G4VisAttributes* visAttributes20 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
DetectorTube_Logical_Sleeve->SetVisAttributes(visAttributes20);

// 13.) Mask Holder
G4Tubs* MaskHolder_Solid_Sleeve
    = new G4Tubs("MaskHolder", // its name
        (2.3496)*cm, // innerR
        (2.6987)*cm, // outer radius
        (16.51)*cm, // half height
        0.*deg, // start angle
        360.*deg); // end angle

G4LogicalVolume* MaskHolder_Logical_Sleeve
    = new G4LogicalVolume(
        MaskHolder_Solid_Sleeve, // its solid
        AlAlloy6061, // its material
        "MaskHolder"); // its name

G4VPhysicalVolume* MaskHolder_Physical_Sleeve
    = new G4PVPlacement(
        0, // no rotation
        G4ThreeVector(0.*cm,0.*cm,(-19.2896)*cm), // center
        MaskHolder_Logical_Sleeve, // its logical volume
        "MaskHolder", // its name
        worldLV, // its mother volume
        false, // no boolean operation
        0, // copy number
        fCheckOverlaps); // checking overlaps
// Mask holder visualization
G4VisAttributes* visAttributes21 = new G4VisAttributes(G4Colour(0.5, 0.5,
0.5)); // Gray
MaskHolder_Logical_Sleeve->SetVisAttributes(visAttributes21);

// End of Defining Geometry

return worldPV;
}

// ===== Convert DetectLV to Sensitive Detector Volume
// =====
void B4DetectorConstruction::ConstructSDandField()
{
    G4SDManager::GetSDMpointer()->SetVerboseLevel(1);
    auto absDetector = new G4MultiFunctionalDetector("Detector");
    G4SDManager::GetSDMpointer()->AddNewDetector(absDetector);
    SetSensitiveDetector("DetectLV",absDetector);
}

```